

1/2




Fig.1




Fig.2

2/2

FUEL CELL	BATTERY	OUTPUT POWER	OPERATION
Lo	Lo	Lo	SET FUEL CELL TO Hi AND CHARGE BATTERY
Lo	Lo	Hi	SET FUEL CELL TO Hi, BUT IF SUFFICIENT POWER CANNOT BE SUPPLIED, SHUT DOWN
Lo	Hi	Lo	STAND BY
Lo	Hi	Hi	SET FUEL CELL TO Hi. DISCHARGE BATTERY UNTIL COMPLETION
Hi	Lo	Lo	CHARGE BATTERY
Hi	Lo	Hi	DISCHARGE FUEL CELL, AND IF EXTRA POWER CAN BE SUPPLIED, CHARGE BATTERY
Hi	Hi	Lo	SET FUEL CELL TO Lo. RETURN TO STANDBY
Hi	Hi	Hi	DISCHARGE FUEL CELL AND BATTERY

Fig.3




Fig.4